

Dedicated to improving vehicle fun, safety & performance

# **Installation Instructions**

# Gear Shift Knob Button for 850 and 70 series 1993-2000 *ipd* #2K85070



# **SUGGESTED TOOLS**

small flat blade screwdriver

### SAFETY WARNINGS

• Time: 1.0 hours Skill level: 2

## INSTALLATION

Remove the shift knob by pulling up sharply with moderate to heavy force. Be careful not to damage any other interior parts in the car while removing the shift knob as it can be difficult to break free from the shift selector. The knob is force fit onto the shift lever, it is not mechanically fastened to the lever. To remove it, set the parking brake and shift the transmission into low gear. You'll need to switch the ignition on to override the shift interlock system, but do not start the car. From the back seat, reach through and with both hands pull on the knob to remove it. Considerable force is required to remove the knob. We have found that wiggling (the knob, not yourself!) while pulling helps. Brace yourself so you don't dent the roof when it comes loose.





11744 NE Ainsworth Circle, Portland, OR 97220 • (503) 257-7500 • Fax (503) 257-7596

2 With the shift knob removed use a small flat blade screw driver to push the release arm from within the shift knob housing.



3 With the shift knob release button exposed, use the screw driver to pull the button away from the housing and expose the internal spring.



Use the screw driver to release the internal spring from the release button.



4



Now remove the release button from the housing by pulling it out and away from the shift knob.



6 Note the original orientation of the original internal spring and replace it with the new included.





8

9

Transfer the steel rod from the old release knob to the new release knob.



Now snap the release knob back into the housing as shown.



Reposition the internal spring back onto the release knob using a small flat blade screwdriver.



Finally, snap the release knob back into position into the housing. If you have trouble getting the release knob back into the housing DO NOT FORCE IT. Instead double check that the steel rod is centered in the release knob and then reinsert into the housing.



Install the shift knob back onto the shift selector, use moderate force to reattach the unit by pressing downward with a sharp 'smack' with your palm.



Reposition the shift selection boot back onto the shift knob.



# WARRANTY

#### **One Year Limited Warranty**

ipd warrants to the original purchaser that the parts manufactured and/or sold by ipd (the Product) is free from defects in material and workmanship under normal use. ipd warrants that the Product will perform substantially in accordance with the specifications set forth in the documentation provided with it. The above express warranties are made for a period of the lesser of 12,000 miles or 12 months from the date the Product is installed in your vehicle.

Any improper use, operation beyond capacity, substitution of parts not approved by ipd in writing, any alteration or repair by others, or any removal, defacing or altering of the identification shall void this warranty. There is no warranty on high-performance or race related parts due to the nature of usage.

The purchaser shall notify ipd at 1-800-444-6473 of any defect within the warranty period no later than thirty (30) days after purchaser discovers the defect. Should any failure to conform to this warranty appear within the warranty period, ipd shall, on notification, correct the nonconformity at its option, either by repairing any defective part, or by making available, FOB ipd's plant, a repaired or replacement part. The purchaser must insure any defective item being returned because ipd does not assume risk of loss or damage while in transit. No payment or reimbursement shall be made for installation, removal, transportation or other charges. The remedies set forth in this instrument are exclusive, and the liability of ipd with respect to any sale shall not exceed the price of the product on which the liability is based.

EXCEPT AS STATED OTHERWISE IN THIS WARRANTY, ipd MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. ipd shall not in any case be liable for special, incidental, consequential, indirect, or other similar damages arising from any breach of these warranties even if ipd or its agent has been advised of the possibility of such damages. Some states do not allow the exclusion or limitation of incidental or consequential damages so the above limitation or exclusion may not apply to you.

This warranty is governed by the laws of the State of Oregon.

